

AND-DNV3N3-4C

Networking Micro Box

- *Intel® Denverton® SoC*
- *8 GbE Copper*
- *2 SFP+*



User Manual

Acrosser Technology Co., Ltd.
www.acrosser.com

Disclaimer

For the purpose of improving reliability, design and function, the information in this document is subject to change without prior notice and does not represent a commitment on the part of Acrosser Technology Co., Ltd.

In no event will Acrosser Technology Co., Ltd. be liable for direct, indirect, special, incidental, or consequential damages arising out of the use or inability to use the product or documentation, even if advised of the possibility of such damages.

Copyright

This document contains proprietary information protected by copyright. All rights are reserved. No part of this manual may be reproduced by any mechanical, electronic, or other means in any form without prior written permission of Acrosser Technology Co., Ltd.

Trademarks

The product names appear in this manual are for identification purpose only. The trademarks and product names or brand names appear in this manual are the property of their respective owners.

Purpose

This document is intended to provide the information about the features and use of the product.

Audience

The intended audiences are technical personnel, not for general audiences.

Ver: 100-001

Date: May 7, 2020

To read this User Manual on your smart phone, you will have to install an APP that can read PDF file format first. Please find the APP you prefer from the APP Market.

Table of Contents

1. System Introduction	5
1.1. Specifications	5
1.2. Package Contents	7
1.3. Optional DDR4 List (6 SKUs)	7
1.4. System Dissection	8
1.4.1. Dimensions	8
1.4.2. Front I/O Panel	9
1.4.3. Rear I/O Panel	10
2. Components Assembly	11
2.1. HDD/SSD Installation	11
2.2. PCB Parts Description	13
3. BIOS Settings	14
3.1. Main Setup	14
3.2. Advanced Setup	15
3.2.1. W83627DHG Hardware Monitor	16
3.2.2. Serial Port Console Redirection	16
3.2.2.1. Serial Port Console Redirection Settings	17
3.2.3. Network Stack Configuration	17
3.2.4. CSM Configuration	18
3.2.5. USB Configuration	18
3.3. Platform Configuration	19
3.3.1. Processor Configuration	19
3.3.2. Memory Configuration	20
3.3.3. South Bridge Chipset Configuration	21
3.3.3.1. South Bridge Chipset Configuration	22
3.4. Boot Setup	23
3.5. Security Setup	24
3.6. Save & Exit Setup	25
4. Software Installation and Programming Guide	26
4.1. Introduction	26
4.1.1. Environment	26
4.1.2. GPIO	26
4.1.3. Watchdog	26
4.2. File Descriptions	26
4.2.1. GPIO/Watchdog/LAN Bypass Subsystem Module	26
4.3. API List and Descriptions	27
4.3.1. GPIO	27

4.3.2. Watchdog	27
4.3.3. Notes	28
5. FAQ	29
Q 1. Where is the serial number located on my system?	29

1. System Introduction

The AND-DNV3N3-4C networking product is based on Intel's Atom C3000, powerful and scalable for vary application scenarios.

The AND-DNV3N3-4C provides a flexible system expansion versatility by supporting from Intel Atom C3558(4 core) with 8x GbE copper LANs and 2x 10G fiber networks (SFP+). Furthermore, in the system design, there are one 2.5-inch HDD/SSD and two Mini PCIe slots to support the latest WLAN function (IEEE 802.11 a/b/g/n/ac) and 4G LTE feature as well.

1.1. Specifications

(Specifications are subject to change without notice.)

General

Thermal Solution	<ul style="list-style-type: none"> Fanless, Passive heat dissipation 															
CPU	<ul style="list-style-type: none"> Intel® Denverton® C3558 4 cores, 2.2GHz 															
Memory	<ul style="list-style-type: none"> 1x SO-DIMM DDR4 															
BIOS	<ul style="list-style-type: none"> Support Console Re-direction Support Bypass Setting <table border="1" data-bbox="468 810 1065 970"> <thead> <tr> <th>Status</th> <th>Normal</th> <th>Bypass</th> </tr> </thead> <tbody> <tr> <td>SYS (ON)</td> <td>V</td> <td></td> </tr> <tr> <td>SYS (OFF)</td> <td></td> <td>V</td> </tr> <tr> <td>WDT (Timeout)</td> <td></td> <td>V</td> </tr> <tr> <td>PWR (Lost)</td> <td colspan="2">Remained prior status</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Support PXE boot from all RJ-45 Coppers 	Status	Normal	Bypass	SYS (ON)	V		SYS (OFF)		V	WDT (Timeout)		V	PWR (Lost)	Remained prior status	
Status	Normal	Bypass														
SYS (ON)	V															
SYS (OFF)		V														
WDT (Timeout)		V														
PWR (Lost)	Remained prior status															

Network Interface

Ethernet (on-board)	<ul style="list-style-type: none"> 8x Copper, 2/4x SFP+ Intel i211, LAN [1:8] Copper SoC embedded SFI, SFP+[1:2]
----------------------------	---

Storage

HDD Bay	<ul style="list-style-type: none"> 1x 2.5" Internal HDD Bay
CFast	<ul style="list-style-type: none"> 1x CFast socket

I/O

Front Panel	<ul style="list-style-type: none">• Ethernet Link/Act LED x8 (LAN[1:8])• Ethernet 1000M LED x8 (LAN[1:8])• Ethernet 100/10M LED x8 (LAN[1:8])• SFP+ Link LED x2• SFP+ Act LED x2• Sys Power LED x1 (12V)• Storage LED x1
Rear Panel	<ul style="list-style-type: none">• Reset button• 2x USB 3.0• 1x RJ45 Console Port• 2x SFP+• 8x GbE LAN (Copper)• 4x Antenna holes for SMA connector (for WLAN & WWAN module)• 1x DC-in connector for 12V input
Internal I/O	<ul style="list-style-type: none">• 1x mini-PCIe connector (for Wi-Fi IEEE 802.11 a/b/g/n/ ac 3T3R module)• 1x mini-PCIe connector (w USB 2.0+3.0 signal only, for 4G module only, USB 3.0)• 1x SATA3+power connector• GPIO pin header

Other Features

Watchdog Timer	<ul style="list-style-type: none">• Software programmable 0~255 Seconds, 0=disable timer.
Battery	<ul style="list-style-type: none">• Lithium Battery, 3V 220mAH (CR2032), for RTC
Hardware Monitoring	<ul style="list-style-type: none">• CPU Voltage• CPU Temperature• System Temperature

Power Requirement

Power Adapter	<ul style="list-style-type: none">• 12VDC, 40W Adapter
----------------------	--

Software

OS Support	<ul style="list-style-type: none">• Linux Kernel 4.8 & above, (64-bit)
-------------------	--

Mechanical & Environment

Dimension	<ul style="list-style-type: none">• 300(L) x 201(W) x 44(H) mm
------------------	--

Operating Temperature	• 0 ~ 40°C (32 ~ 104°F)
Storage Temperature	• -20 ~ 80°C (-4 ~ 176°F)
Relative Humidity	• 0 to 90% @40°C, non-condensing

EMC & Safety

Certification	• CE, FCC Class A, RoHS 2, cULus
Vibration Test	• IEC 60068-2-64, 5~500Hz, 3GRMS
Drop Test	• ISTA-2A 2006

1.2. Package Contents

Check if the following items are included in the package.

	Item	Q'ty
<input type="checkbox"/>	AND-DNV3N3-4C System	1
<input type="checkbox"/>	Console Cable	1
<input type="checkbox"/>	CD with Driver and Manual	1
<input type="checkbox"/>	Power Adapter (12V)	1
<input type="checkbox"/>	Power Cord	1
<input type="checkbox"/>	Screw Pack	1





1.3. Optional DDR4 List (6 SKUs)

Model Name	Description
AND-DNV3N3-4C	4GB DDR4-2666 memory (ECC)
	8GB DDR4-2666 memory (ECC)
	16GB DDR4-2666 memory (ECC)
	4GB DDR4-2666 memory (Non-ECC)
	8GB DDR4-2666 memory (Non-ECC)
	16GB DDR4-2666 memory (Non-ECC)


1.4. System Dissection

1.4.1. Dimensions

(Unit: mm)




1.4.2. Front I/O Panel



- **Sys Power**
System Power LED
- **Storage**
Storage Active LED
- **LAN 1~8**
LAN 1~8 Link/Active LED
- **SFP+ 1~2**
SFP+ 1~2 Link/Active LED

1.4.3. Rear I/O Panel




- **ANT1 ~ ANT4**
SMA Antenna Hole. Reserved for optional Wi-Fi / BT, 4G LTE antenna.
- **DC 12V**
DC12V Power Input
- **LAN1 ~ LAN8**
RJ45 LAN Port
- **USB**
USB 3.0 Port
- **SFP1 ~ SFP2**
SFP LAN Port
- **Console**
Console Port (RJ45)
- **RST**
Reset Button

2. Components Assembly


Please follow the instruction to install the inner modules.

2.1. HDD/SSD Installation

Step 1: Plug the SATA cable (both the signal and power) in the socket on PCB.




Step 2: Connect the SATA cable with the HDD/SSD.



- Step 3: Fasten the HDD/SSD with 4 screws onto the inner side of the chassis top cover.



- Step 4: Before closing the top cover, pay attention to arrange the cable wire among the PCB components spaces.




Step 5: Fasten the cover with 4 screws.



2.2. PCB Parts Description

There are four modular sockets/slots reserved to install your modules: CFast, Mini-PCle, DDR, and CFast.

Step 1: To install the CFast, you will have to remove the fixing screw first, and then have it fastened after inserting the module.



3. BIOS Settings


This chapter describes the BIOS menu displays and explains how to perform common tasks needed to get the system up and running. It also gives detailed explanation of the elements found in each of the BIOS menus. The following topics are covered:

- Main Setup
- Advanced Setup
- Chipset Setup
- Boot Setup
- Security Setup
- Save & Exit Setup

Once you enter the Award BIOS™ CMOS Setup Utility, the Main Menu will appear on the screen. Use the arrow keys to highlight the item and then use the <Pg Up> <Pg Dn> keys to select the value you want in each item.

3.1. Main Setup


The BIOS setup main menu includes some options. Use the [Up/Down] arrow key to highlight the option, and then press the [Enter] key to select the item and configure the functions.



Note: Listed at the bottom of the menu are the control keys. If you need any help with the item fields, you can press <F1> key, and it will display the relevant information.


- **System Date**
Set the system date.
- **System Time**
Set the system time.

3.2. Advanced Setup




- **W83627DHG HW Monitor**
Dsiplay hardware monitor status.
- **Serial Port Console Redirection**
Console port setting.
- **Network Stack Configuration**
Network stack setting.
- **CSM Configuration**
Compatibility Support Module Configuration. Enable/Disable Option ROM execution settings, etc.
- **NVMe Configuration**
Set NVMe configuration.
- **USB Configuration**
Set USB configuration parameters.

3.2.1. W83627DHG Hardware Monitor



3.2.2. Serial Port Console Redirection



3.2.2.1. Serial Port Console Redirection Settings

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.	
Advanced	
COM 1 Console Redirection Settings	The setting specify how the host computer and the remote computer will exchange data. Both computers should have the same or compatiabile settings.
Terminal Type [ANSI]	---: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Bits per second [115200]	
Date bits [8]	
Parity [None]	
Stop Bits [1]	
Flow Control [None]	
VT-UTF8 Combo Key Support [Enable]	
Recorder Mode [Disable]	
Resoulution 100*31 [Disable]	
Putty KeyPad [VT100]	
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.	

3.2.3. Network Stack Configuration

Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.	
Advanced	
Network Stack [Disable]	The setting specify how the host computer and the remote computer will exchange data. Both computers should have the same or compatiabile settings.
	---: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.	


3.2.4. CSM Configuration

<p>Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.</p> <p>Advanced</p>		
<p>CSM Support</p>	<p>[Disable]</p>	<p>The setting specify how the host computer and the remote computer will exchange data. Both computers should have the same or compatible settings.</p>
		<p>---: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>
<p>Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.</p>		


3.2.5. USB Configuration

<p>Aptio Setup Utility - Copyright (C) 2012 American Megatrends, Inc.</p> <p>Advanced</p>		
<p>USB Configuration</p> <p>USB Module Version</p> <p>USB Controllers :</p> <p>USB Devices:</p> <p>Legacy USB Support</p> <p>XHCI Hand-off</p>	<p>19</p> <p>[Enable]</p> <p>[Enable]</p>	<p>The setting specify how the host computer and the remote computer will exchange data. Both computers should have the same or compatible settings.</p>
		<p>---: Select Screen ↑↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</p>
<p>Version 2.15.1226. Copyright (C) 2012 American Megatrends, Inc.</p>		

3.3. Platform Configuration




3.3.1. Processor Configuration



- **EIST (GV3)**
Enable/Disable EIST.


- **Turbo**
Enable/Disable CPU Turbo capability.

3.3.2. Memory Configuration




- **Memory Frequency**
Memory speed

3.3.3. South Bridge Chipset Configuration




- **SATA Configuration**
Configuration of SATA controller.
- **State After G3**
Specify what state to go to when power is re-applied after a power failure (G3 state).


3.3.3.1. South Bridge Chipset Configuration



- **SATA 0**
Configuration of sata controller




- **Enable controller**
Enables/Disables SATA Controller if supported by current cpu SKU.




- **Enable/Disable port**
Enables/Disables SATA Controller port if supported by current cpu SKU.
- **Hot plug**
Enables/Disables Hot plug

3.4. Boot Setup




- **Boot Logo**
Enables or disables Quiet Boot option.
- **Launch PXE OpROM policy**
This option controls the execution of UEFI and Legacy PXE OpROM.
- **Boot Option Priorities**
Set the system boot order.
- **Network Device BBS Priorities**
Set the order of the legacy devices in this group.

3.5. Security Setup



- **Administrator Password**
Set Administrator Password.

3.6. Save & Exit Setup



- **Save Changes and Exit**
Exit system setup after saving the changes.
- **Discard Changes and Reset**
Exit system setup without saving any changes.
- **Restore Defaults**
Restore/Load the default values for all the set up options.

4. Software Installation and Programming Guide

4.1. Introduction

4.1.1. Environment

This test utility develop is based on kernel 4.8 above (Ubuntu 18.04.1 Server 64bit).

4.1.2. GPIO

The AND-DNV3N3-4C provides GPIO interface. Users can use the GPIO APIs to control GPO Pin.

4.1.3. Watchdog

The AND-DNV3N3-4C provides a Watchdog Timer. Users can use the Watchdog APIs to configure and to access the Watchdog timer. The Watchdog timer can be set to 1~255 seconds. Setting the timer to zero disables the timer. The remaining seconds of the timer to reboot can be read from the timer.

4.2. File Descriptions

4.2.1. GPIO/Watchdog/LAN Bypass Subsystem Module

1. TestUtility.exe

The GPIO, Watchdog, Console user interface bin binary.

2. Libw83627.h

This file includes the declarations of the APIs and macro definitions.

3. Libw83627.a

The static library for linux.

4. Libw83627.so

The dynamic library for linux.

5. Install_driver

This file is linux shell script file. Run this file can help you install environment and modprobe driver on linux.

6. readme

Use this utility first. Please read the readme file first.

4.3. API List and Descriptions

4.3.1. GPIO

Syntax:	Get_gpi_status(int pin)
Description:	Get the status of GPIO input pins status.
Parameters:	This function fills in an integer variable as the parameter. The pin0 ~ pin1 is the status of the input pins.
Return Value:	1: HIGH, 0: LOW.

Syntax:	Get_gpo_status(int pin)
Description:	Get the status of GPIO output pins status.
Parameters:	This function fills in an integer variable as the parameter. The pin0 ~ pin1 is the status of the output pins.
Return Value:	1: HIGH, 0: LOW.

Syntax:	Set_gpo(int pin, int value)
Description:	Set the status of GPIO output value.
Parameters:	Set value 0 is Low, 1 is High
Return Value:	If the function sets the values successfully, it returns 0 or -1, any other returned value stands for error.

4.3.2. Watchdog

Syntax:	Void wdt_start(int _timevalue)
Description:	This function gets the watchdog timer register to the timevalue and starts to count down.
Parameters:	The parameter 'val' is the value to set to watchdog timer register. The range is 1 ~ 255.
Return Value:	This function returns the value of the time counter and returns it to the caller as an unsigned integer.

Syntax:	Void wdt_stop(void)
Description:	This function sets the watchdog timer stop.
Parameters:	None.
Return Value:	None.

4.3.3. Notes


Syntax:	int libw83627_init(void)
Description:	Must call this function first before using the watchdog and gpio function.
Parameters:	None.
Return Value:	0: Successful, -1: Fail

Syntax:	void lib_close(void)
Description:	If not using watchdog and gpio fuction on your program, please call this function.
Parameters:	None.
Return Value:	None.

5. FAQ

Q 1. *Where is the serial number located on my system?*

- The serial number (S/N) is an alpha-numeric character located on the bottom or side chassis.



(for reference only)

Technical Support Form

We deeply appreciate your purchase of Acrosser products. Please find the “**tech_form.doc**” file in our utility CD. If you have any questions or problems about Acrosser products, please fill in the following information. We will answer your questions in the shortest time possible.

Describe Your Info and Acrosser System Info

- Your Company Name: _____
- Your Contact Info: _____ Phone Number: _____
- Your E-Mail Address: _____
- Your Company Address: _____

- Acrosser Model Name: _____
- Acrosser Serial Number: _____

Describe System Configuration

- CPU Type: _____
- Memory Size: _____
- Storage Device (e.g. HDD, CF, or SSD): _____
- Additional Peripherals (e.g. Graphic Card): _____
- Operating System & Version (e.g. Windows 7 Embedded): _____
- Special API or Driver: _____
(If yes, please provide it for debug.)
- Running Applications: _____
- Others: _____

Describe Your Problems or Questions:

Send the above information to one of the following Acrosser contacts:

- Acrosser Local Sales Representative
- Acrosser Authorized Sales Channels
- Acrosser Inquiry --- <http://www.acrosser.com/inquiry.html>
- Acrosser FAX Number --- 886-2-29992887

To Make Your **Embedded** Idea a Reality



Acrosser Headquarters

241新北市三重區光復路一段61巷26號10樓
10F., No.26, Ln. 61, Sec. 1, Guangfu Rd.,
Sanzhong Dist., New Taipei City 241, Taiwan
(R.O.C.)

TEL: +886-2-29999000

FAX: +886-2-29992887 / +886-2-29993960

Acrosser Taichung Office

414台中市烏日區僑仁街8號10樓之1
10F.-1, No.8, Qiaoren St., Wuri Dist.,
Taichung City 414, Taiwan (R.O.C.)

TEL: +886-4-2337-0715

FAX: +886-4-2337-3422

Acrosser China Subsidiary

深圳市欣扬通电子有限公司
深圳市福田区泰然八路安华工业区6号楼7层
706室 (邮编: 518040)

Room 706, floor 7, building 6, Anhua Industrial
Zone, Tairan 8th Road, Futian District, Shenzhen,
China (Postal: 518040)

TEL: +86-755-83542210

FAX: +86-755-83700087

Acrosser Nanjing Office

欣扬通电子有限公司 南京办事处
江苏省南京市江宁区天元东路228号504室
(邮编: 211100)

Room 504, No. 228, Tian Yuan East Rd.,
Jiang Ning Dist., Nanjing City, Jiangsu Province,
China (Postal: 211100)

Mobile: 13611932003

TEL: +86-025-86137002

FAX: +86-025-86137003

Acrosser Beijing Office

欣扬通电子有限公司 北京办事处
北京市昌平区沙河镇沙阳路巩华新村8号楼2单元
1403室 (邮编: 102206)

Room 1403, Unit 2, Building 8, Gonghua Village,
Shahe Town, Changping District, Beijing, China
(Postal: 102206)

Mobile: 13311317329

Acrosser USA Inc.

8351 Elm Ave. Suite 107, Rancho Cucamonga,
CA91730, USA

TEL: +1-909-476-0071

FAX: +1-909-466-9951